

			DRW. DR100023_00	SPARE-PARTS													
SPARE-PARTS			VLR32	SPARE-PARTS KIT TABLE													
RECOMMENDED PARTS KIT			COMPONENT REF. No.	PUMP MODEL													
KIT REF. No.	KIT DESCRIPTION	COMPONENT REF. No.	COMPONENT DESCRIPTION	VLR32-1 F T	VLR32-2 F T	VLR32-3 F T	VLR32-4 F T	VLR32-5 F T	VLR32-6 F T	VLR32-7 F T	VLR32-8 F T	VLR32-9 F T	VLR32-10 F T	VLR32-11 F T	VLR32-12 F T	VLR32-13 F T	VLR32-14 F T
82	TIE ROD KIT (PUMP BODY -)	328 214 97	ROD WASHER NUT (TIE ROD LOCKING -)	ZBR34880 4 pc 4 pc	ZBR33580 4 pc 4 pc	ZBR33600 4 pc 4 pc	ZBR34370 4 pc 4 pc	ZBR34920 4 pc 4 pc	ZBR34930 4 pc 4 pc	ZBR34940 4 pc 4 pc	ZBR34950 4 pc 4 pc	ZBR33670 4 pc 4 pc	ZBR34970 4 pc 4 pc	ZBR34980 4 pc 4 pc	ZBR34990 4 pc 4 pc	ZBR35000 4 pc 4 pc	ZBR35010 4 pc 4 pc
200	BOLTS AND SCREWS KIT	4 158 165 102 105 107 109 237 274 417	SCREW SCREW (STOP -) WASHER (BEARING LOCK -) SCREW (SEAL HOLDER FLANGE -) SCREW REW (MOTOR LOCKING - / INTERNAL SUPPD NUT (MOTOR LOCKING -) SCREW (COUPLING -) GUARD COUPLING SCREW PIN								ZBR34890						
201	GASKET KIT	78 6 228 25 333	NOZZLE (AIR -) GASKET (FILL/DRAIN PLUG -) GASKET (ANTI-VIBRATION -) O-RING (PUMP BODY -) PLUG (SIDE -)								ZBR34900						
323	STAGE (INTERMEDIATE -)KIT	21 73 319 273 276 277 9	IMPELLER NUT BUSHING (CONIC -) RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) DIFFUSER								ZBR34910						
356	MOTOR COMPLETE KIT	289 228	MOTOR (COMPLETE - W/ IMPELLER) GASKET (ANTI-VIBRATION -)								ZBR34960						
* 371	MECHANICAL SEAL KIT	24 482	SEAL (COMPLETE MECHANICAL -) ADJUSTMENT SPACER								ZBR35020						
374	HYDRAULIC KIT WITH BEARING	21 73 319 273 276 277 289 487	IMPELLER NUT BUSHING (CONIC -) RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) HAMMER (DIFFUSER-BEARING-RING INTERM BEARING								ZBR35030						
384	PUMP BODY KIT	288	BASE (PUMP -)								ZBR35040						
402	MOTOR KIT	488	COMPLETE MOTOR	ZBR35050 1 pc	ZBR35060 1 pc	ZBR35070 1 pc	ZBR33530 1 pc	ZBR34030 1 pc	ZBR34040 1 pc	ZBR35080 1 pc	ZBR35090 1 pc	ZBR35100 1 pc	ZBR35110 1 pc	ZBR35120 1 pc	ZBR35130 1 pc	ZBR35140 1 pc	ZBR35150 1 pc
404	SHAFT KIT	232 476 92 108 413	SHAFT BUSHING WASHER WASHER (TOOTHED -) SCREW	ZBR35110 1 pc	ZBR35120 1 pc	ZBR35130 1 pc	ZBR35140 1 pc	ZBR35150 1 pc	ZBR35160 1 pc	ZBR35170 1 pc	ZBR35180 1 pc	ZBR35190 1 pc	ZBR35200 1 pc	ZBR35210 1 pc	ZBR35220 1 pc	ZBR35230 1 pc	ZBR35240 1 pc
405	COUPLING KIT	237 103	SCREW (COUPLING -) COUPLING (MOTOR PUMP -)	ZBR35250 4 pc	ZBR35260 4 pc	ZBR35270 4 pc				ZBR35280 4 pc		ZBR35290 4 pc				ZBR35300 4 pc	
406	LANTERN KIT	27	LANTERN	ZBR35310 1 pc	ZBR35320 1 pc	ZBR35330 1 pc				ZBR35340 1 pc						ZBR35330 1 pc	
411	GUARD COUPLING KIT	274 414	GUARD COUPLING SCREW GUARD COUPLING	ZBR35350 4 pc		ZBR35360 4 pc				ZBR35370 4 pc						ZBR35360 4 pc	
437	RING (GUIDE -) KIT	158 165 278	SCREW (STOP -) WASHER (BEARING LOCK -) RING (BEARING -)							ZBR35380							
452	HYDRAULIC KIT, FIRST STAGE	21 73 319 273 276 277 284 417	IMPELLER NUT BUSHING (CONIC -) RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) INTERCONNECTOR (COMPLETE SUCTION -) PIN								ZBR35390						
453	SUPPORT FLANGE KIT	36 463	RING (ELASTIC -) FLANGE								ZBR35400						
474	SLEEVE KIT	25 83 273	O-RING (PUMP BODY -) SLEEVE RING (STOP -)	ZBR35410 2 pc	ZBR35420 2 pc	ZBR35430 2 pc	ZBR35440 2 pc	ZBR35450 2 pc	ZBR35460 2 pc	ZBR35470 2 pc	ZBR35480 2 pc	ZBR35490 2 pc	ZBR35500 2 pc	ZBR35510 2 pc	ZBR35520 2 pc	ZBR35530 2 pc	ZBR35540 2 pc
* 475	WEAR RINGS KIT	276 277	RING (STOP -) SUPPORT (GUIDE RING -)								ZBR35550						
483	CHAMBER (UPPER - WITH DIFFUSER)KIT	308	CHAMBER (UPPER - WITH DIFFUSER)								ZBR35560						
484	RECYCLING PLUG KIT	5 6	PLUG (FILL -) GASKET (FILL/DRAIN PLUG -)								ZBR35570						
523	TIE ROD KIT (PUMP BODY -)	336 523	NUT TIE ROD KIT (PUMP BODY -)	ZBR35580 2 pc	ZBR35590 2 pc	ZBR35600 2 pc	ZBR35610 2 pc	ZBR35620 2 pc	ZBR35630 2 pc	ZBR35640 2 pc	ZBR35650 2 pc	ZBR35660 2 pc	ZBR35670 2 pc	ZBR35680 2 pc	ZBR35690 2 pc	ZBR35700 2 pc	ZBR35710 2 pc
525	MOTOR ADAPTOR KIT	524	MOTOR ADAPTOR													ZBR35720	
527	FLANGE KIT	526	FLANGE								ZBR35730						