

				DRW. DR100016	SPARE-PARTS																								
SPARE-PARTS				VLRI 8	PUMP MODEL																								
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	VLRI 8-20F M	VLRI 8-20F T	VLRI 8-30F M	VLRI 8-30F T	VLRI 8-40F M	VLRI 8-40F T	VLRI 8-50F T	VLRI 8-60F T	VLRI 8-80F T	VLRI 8-100F T	VLRI 8-120F T	VLRI 8-140F T	VLRI 8-160F T	VLRI 8-180F T	VLRI 8-200F T										
	82	TIE ROD KIT (PUMP BODY -)	339 214 97	ROD WASHER NUT (TIE ROD LOCKING -)	ZBR33560	4 pc 4 pc 4 pc	ZBR33570	4 pc 4 pc 4 pc	ZBR33580	4 pc 4 pc 4 pc	ZBR33590	4 pc 4 pc 4 pc	ZBR33600	4 pc 4 pc 4 pc	ZBR33610	4 pc 4 pc 4 pc	ZBR33620	4 pc 4 pc 4 pc	ZBR33630	4 pc 4 pc 4 pc	ZBR33640	4 pc 4 pc 4 pc	ZBR33650	4 pc 4 pc 4 pc	ZBR33660	4 pc 4 pc 4 pc	ZBR33670	4 pc 4 pc 4 pc	
	200	BOLTS AND SCREWS KIT	66 274 237 105 273 4	SCREW GUARD COUPLING SCREW SCREW (COUPLING -) SCREW RING (STOP -) SCREW								ZBR32880																	2 pc 2 pc 4 pc 4 pc 1 pc 4 pc
	201	GASKET KIT	78 6 25	NOZZLE (AIR -) GASKET (FILL/DRAIN PLUG -) O-RING (PUMP BODY -)								ZBR33680																	1 pc 2 pc 2 pc
*	371	MECHANICAL SEAL KIT	482 266 267	ADJUSTMENT SPACER SEAL (STATIONARY -) SEAL (ROTATING -)								ZBR22310																	1 pc 1 pc 1 pc
	323	STAGE (INTERMEDIATE -)KIT	21 478 277 276 9	IMPELLER SPACER SUPPORT (GUIDE RING -) RING (GUIDE -) DIFFUSER								ZBR33120																	1 pc 1 pc 1 pc 1 pc 1 pc
	373	HYDRAULIC KIT, LAST STAGE	21 477 478 277 276 9	IMPELLER SPACER SPACER SUPPORT (GUIDE RING -) RING (GUIDE -) DIFFUSER								ZBR33890																	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc
	374	HYDRAULIC KIT WITH BEARING	21 479 276 277 487 290	IMPELLER SPACER RING (GUIDE -) SUPPORT (GUIDE RING -) BEARING CHAMBER (DIFFUSER-BEARING-RING INTERM. -)								ZBR33130																	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc
	384	PUMP BODY KIT	288	BASE (PUMP -)								ZBR33690																	1 pc
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR21210	1 pc	ZBR21220	1 pc	ZBR30710	1 pc	ZBR21230	1 pc	ZBR30720	1 pc	ZBR21300	1 pc	ZBR30730	1 pc	ZBR21250	1 pc	ZBR26630	1 pc	ZBR31110	1 pc	ZBR33530				1 pc
	404	KIT ALBERO	232 71 73 166	SHAFT WASHER NUT WASHER (SEAL COMPRESSION -)	ZBR33700	1 pc 1 pc 1 pc 1 pc	ZBR33710	1 pc 1 pc 1 pc 1 pc	ZBR33720	1 pc 1 pc 1 pc 1 pc	ZBR33730	1 pc 1 pc 1 pc 1 pc	ZBR33740	1 pc 1 pc 1 pc 1 pc	ZBR33750	1 pc 1 pc 1 pc 1 pc	ZBR33760	1 pc 1 pc 1 pc 1 pc	ZBR33770	1 pc 1 pc 1 pc 1 pc	ZBR33780	1 pc 1 pc 1 pc 1 pc	ZBR33790	1 pc 1 pc 1 pc 1 pc	ZBR33800	1 pc 1 pc 1 pc 1 pc	ZBR33810	1 pc 1 pc 1 pc 1 pc	
	405	COUPLING KIT	275 237 103	PIN (MOTOR COUPLING -) SCREW (COUPLING -) COUPLING (MOTOR PUMP -)	ZBR33280	1 pc 4 pc 1 pc	ZBR33290	1 pc 4 pc 1 pc	ZBR33280	1 pc 4 pc 1 pc	ZBR33290	1 pc 4 pc 1 pc	ZBR33300	1 pc 4 pc 1 pc	ZBR33310	1 pc 4 pc 1 pc	ZBR33310	1 pc 4 pc 1 pc	ZBR33310	1 pc 4 pc 1 pc	ZBR33310	1 pc 4 pc 1 pc	ZBR33310	1 pc 4 pc 1 pc	ZBR33310	1 pc 4 pc 1 pc	ZBR33310	1 pc 4 pc 1 pc	1 pc 4 pc 1 pc
	406	LANTERN KIT	27	LANTERN	ZBR33820	1 pc	ZBR33830	1 pc	ZBR33820	1 pc	ZBR33830	1 pc	ZBR33840	1 pc	ZBR33850	1 pc	ZBR33850	1 pc	ZBR33850	1 pc	ZBR33850	1 pc	ZBR33850	1 pc	ZBR33850	1 pc	ZBR33850	1 pc	1 pc
	411	GUARD COUPLING KIT	274 414	GUARD COUPLING SCREW GUARD COUPLING	ZBR30350	2 pc 2 pc	ZBR30360	1 pc 1 pc	ZBR30350	2 pc 2 pc	ZBR30360	2 pc 2 pc	ZBR30360	2 pc 2 pc	ZBR30360	2 pc 2 pc	ZBR30360	2 pc 2 pc	ZBR30360	2 pc 2 pc	ZBR30360	2 pc 2 pc	ZBR30360	2 pc 2 pc	ZBR30360	2 pc 2 pc	ZBR30360	2 pc 2 pc	4 pc 2 pc 1 pc
	452	HYDRAULIC KIT, FIRST STAGE	284 21 435 276 277	INTERCONNECTOR (COMPLETE SUCTION -) IMPELLER SPACER RING (GUIDE -) SUPPORT (GUIDE RING -)								ZBR34460																	1 pc 1 pc 1 pc 1 pc
	455	BASE KIT	163	BASE								ZBR33860																	1 pc
	474	SLEEVE KIT	25 83	O-RING (PUMP BODY -) SLEEVE	ZBR33380	2 pc 1 pc	ZBR33390	2 pc 1 pc	ZBR33400	2 pc 1 pc	ZBR33410	2 pc 1 pc	ZBR33420	2 pc 1 pc	ZBR33430	2 pc 1 pc	ZBR33440	2 pc 1 pc	ZBR33450	2 pc 1 pc	ZBR33460	2 pc 1 pc	ZBR33470	2 pc 1 pc	ZBR33480	2 pc 1 pc	ZBR33490	2 pc 1 pc	2 pc 1 pc
*	475	WEAR RINGS KIT	276 277	RING (GUIDE -) SUPPORT (GUIDE RING -)								ZBR33500																	1 pc 1 pc
	483	CHAMBER (UPPER - WITH DIFFUSER)KIT	486 308	CONICAL SPRING CHAMBER (UPPER - WITH DIFFUSER)								ZBR33510																	1 pc 1 pc
	484	RECYCLING PLUG KIT	6 86	GASKET (FILL/DRAIN PLUG -) PLUG (RECYCLING -)								ZBR33880																	2 pc 2 pc
	494	COWLING KIT	493 21	COWLING IMPELLER								ZBR33870																	2 pc 1 pc
	498	HYDRAULIC KIT WITH BEARING AND SPACER	479 276 277 477 487 290	SPACER RING (GUIDE -) SUPPORT (GUIDE RING -) SPACER BEARING CHAMBER (DIFFUSER-BEARING-RING INTERM. -)	ZBR33900	1 pc 1 pc 1 pc 1 pc 1 pc 1 pc																							1 pc 1 pc 1 pc 1 pc 1 pc 1 pc

Ricambi validi per i modelli con codice E3Bxxxx/E3Exxxxx, per i modelli dove in etichetta non è presente alcun codice prodotto contattare il ns. ufficio Post-Vendita
 Spare parts valid for models E3Bxxxx/E3Exxxxx. For models which is not indicated Part number, please contact our After Sales
 Pièces détachées valables pour les modèles E3Bxxxx/E3Exxxxx. Pour les modèles pour lesquels il n'y pas d'indication, veuillez contacter notre Service Après Vente
 Ersatzteile gültig für Modelle mit Artikel Nummer E3Bxxxx/E3Exxxxx Für Modelle, die kein Artikel Nummer, bitte nehmen Sie Kontakt mit unser Service Büro