

SPARE-PARTS				VLRI 16	PUMP MODEL											
RECOMMENDED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONENT REF. Nr.	COMPONENT DESCRIPTION	VLRI 16-20 F T	VLRI 16-30 F T	VLRI 16-40 F T	VLRI 16-50 F T	VLRI 16-60 F T	VLRI 16-70 F T	VLRI 16-80 F T	VLRI 16-100 F T	VLRI 16-120 F T	VLRI 16-140F T	VLRI 16-160F T	
	82	TIE ROD KIT (PUMP BODY ~)	339	ROD												
			214	WASHER	ZBR34340	ZBR33580	ZBR34350	ZBR34360	ZBR34370	ZBR33620	ZBR34380	ZBR34390	ZBR34400	ZBR34410	ZBR34420	
			97	NUT (TIE ROD LOCKING ~)												
	200	BOLTS AND SCREWS KIT	66	SCREW												
			274	GUARD COUPLING SCREW												
			237	SCREW (COUPLING ~)												
			105	SCREW												
			273	RING (STOP ~)												
			4	SCREW												
	201	GASKET KIT	78	NOZZLE (AIR ~)												
			6	GASKET (FILL/DRAIN PLUG ~)												
			25	O-RING (PUMP BODY ~)												
*	371	MECHANICAL SEAL KIT	482	ADJUSTMENT SPACER												
			266	SEAL (STATIONARY ~)												
			267	SEAL (ROTATING ~)												
	323	STAGE (INTERMEDIATE ~)KIT	21	IMPELLER												
			478	SPACER												
			277	SUPPORT (GUIDE RING ~)												
			276	RING (GUIDE ~)												
			9	DIFFUSER												
	374	HYDRAULIC KIT WITH BEARING	21	IMPELLER												
			479	SPACER												
			276	RING (GUIDE ~)												
			277	SUPPORT (GUIDE RING ~)												
			487	BEARING												
			290	AMBER (DIFFUSER-BEARING-RING INTERMEDIATE)												
	384	PUMP BODY KIT	288	BASE (PUMP ~)												
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR30730	ZBR21250	ZBR26630	ZBR31110	ZBR33530	ZBR34030	ZBR34040					
	404	KIT ALBERO	232	SHAFT												
			166	WASHER (SEAL COMPRESSION ~)	ZBR34620	ZBR34630	ZBR34640	ZBR34650	ZBR34660	ZBR34670	ZBR34680	ZBR34690	ZBR34700	ZBR34710	ZBR34720	
			71	WASHER												
			73	NUT												
	405	COUPLING KIT	275	PIN (MOTOR COUPLING ~)												
			237	SCREW (COUPLING ~)	ZBR33290	ZBR33300	ZBR33310	ZBR33310	ZBR33310	ZBR33310	ZBR33310	ZBR33310	ZBR33310	ZBR33310	ZBR33310	ZBR33310
			103	COUPLING (MOTOR PUMP ~)												
	406	LANTERN KIT	27	LANTERN	ZBR33830	ZBR33840	ZBR33850	ZBR33850	ZBR33850	ZBR33850	ZBR33850	ZBR33850	ZBR33850	ZBR33850	ZBR33850	ZBR33850
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW	ZBR30360	ZBR30360	ZBR30360	ZBR30360	ZBR30360	ZBR30360	ZBR30360	ZBR30360	ZBR30360	ZBR30360	ZBR30360	ZBR30360
			414	GUARD COUPLING												
	452	HYDRAULIC KIT, FIRST STAGE	284	INTERCONNECTOR (COMPLETE SUCTION ~)												
			21	IMPELLER												
			435	SPACER												
			276	RING (GUIDE ~)												
			277	SUPPORT (GUIDE RING ~)												
	455	BASE KIT	163	BASE												
	474	SLEEVE KIT	25	O-RING (PUMP BODY ~)	ZBR34190	ZBR33400	ZBR34210	ZBR34220	ZBR34230	ZBR33440	ZBR34240	ZBR34250	ZBR34260	ZBR34270	ZBR34280	
			83	SLEEVE												
*	475	WEAR RINGS KIT	276	RING (GUIDE ~)												
			277	SUPPORT (GUIDE RING ~)												
	483	CHAMBER (UPPER ~ WITH DIFFUSER)KIT	486	CONICAL SPRING												
			308	CHAMBER (UPPER ~ WITH DIFFUSER)												
	484	RECYCLING PLUG KIT	6	GASKET (FILL/DRAIN PLUG ~)												
			86	PLUG (RECYCLING ~)												
	494	COWLING KIT	493	COWLING												

Ricambi validi per i modelli con codice E4Bxxxxx /E4Exxxxx, per i modelli dove in etichetta non è presente alcun codice prodotto contattare il ns. ufficio Post-Vendita
 Spare parts valid for models E4Bxxxxx/E4Exxxxx. For models which in label is not indicated Part number, please contact our After Sales
 Pièces détachées valables pour les modèles E4Bxxxxx/E4Exxxxx. Pour les modèles pour lesquels il n'y pas d'indication, veuillez contacter notre Service Après Vente
 Ersatzteile gültig für Modelle mit Artikel Nummer E4Bxxxxx /E4Exxxxx Für Modelle, die kein Artikel Nummer, bitte nehmen Sie Kontakt mit unser Service Büro