

				DRW. DR090010	SPARE-PARTS								
Select language <input type="text" value="English"/>				SPARE-PARTS KIT TABLE									
SPARE-PARTS				VLRI 4	PUMP MODEL								
RECOMMEN DED PARTS KIT	KIT REF. Nr.	KIT DESCRIPTION	COMPONE NT REF. Nr.	COMPONENT DESCRIPTION	VLRI 4-20 A M	VLRI 4-20 A T	VLRI 4-30 A M	VLRI 4-30 A T	VLRI 4-40 A M	VLRI 4-40 A T	VLRI 4-50 A M	VLRI 4-50 A T	
	82	TIE ROD KIT (PUMP BODY -)	97	NUT (TIE ROD LOCKING -)	L=76 Nuovo								
			214	WASHER									
			339	ROD									
	200	BOLTS AND SCREWS KIT	4	SCREW									
			66	SCREW									
			105	SCREW									
			273	RING (STOP -)									
			274	GUARD COUPLING SCREW									
	201	GASKET KIT	25	O-RING (PUMP BODY -)									
			78	NOZZLE (AIR -)									
			87	O-RING (SHUTTER -)									
	323	STAGE (INTERMEDIATE -)KIT	9	DIFFUSER									
			21	IMPELLER									
			276	RING (GUIDE -)									
			277	SUPPORT (GUIDE RING -)									
			478	SPACER									
*	371	MECHANICAL SEAL KIT	266	SEAL (STATIONARY -)									
			267	SEAL (ROTATING -)									
			482	ADJUSTMENT SPACER									
	373	HYDRAULIC KIT, LAST STAGE	9	DIFFUSER									
			21	IMPELLER									
			276	RING (GUIDE -)									
			277	SUPPORT (GUIDE RING -)									
			477	SPACER									
			485	SPACER									
	374	HYDRAULIC KIT WITH BEARING	9	DIFFUSER									
			21	IMPELLER									
			276	RING (GUIDE -)									
			277	SUPPORT (GUIDE RING -)									
			479	SPACER									
			487	BEARING									
	384	PUMP BODY KIT	288	BASE (PUMP -)									
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR21130	ZBR21140	ZBR21150	ZBR21160	ZBR21210	ZBR21220	ZBR30710	ZBR21230	
			71	WASHER									
			73	NUT									
	404	SHAFT KIT	166	WASHER (SEAL COMPRESSION -)	ZBR30220		ZBR30230		ZBR30260		ZBR30870		
			232	SHAFT									
	405	COUPLING KIT	103	COUPLING (MOTOR PUMP -)			ZBR30000		ZBR30010		ZBR30020	ZBR30010	
			237	SCREW (COUPLING -)									
	406	LANTERN KIT	27	LANTERN			ZBR31240		ZBR31250		ZBR31260	ZBR31250	
	411	GUARD COUPLING KIT	274	GUARD COUPLING SCREW			ZBR30350				ZBR30360	ZBR30350	
			414	GUARD COUPLING									
	452	HYDRAULIC KIT, FIRST STAGE	9	DIFFUSER									
			21	IMPELLER									
			276	RING (GUIDE -)									
			277	SUPPORT (GUIDE RING -)									
			435	SPACER									
	455	BASE KIT	163	BASE									
	474	SLEEVE KIT	25	O-RING (PUMP BODY -)	ZBR30460		ZBR31020		ZBR30490		ZBR31030		
			83	SLEEVE									
*	475	WEAR RINGS KIT	276	RING (GUIDE -)									
			277	SUPPORT (GUIDE RING -)									
	483	CHAMBER (UPPER - WITH DIFFUSER)KIT	11	DIFFUSER (DISCHARGE -)									
			36	RING (ELASTIC -)									
	484	RECYCLING PLUG KIT	87	O-RING (SHUTTER -)									
			88	SHUTTER									
	494	COWLING KIT	493	COWLING									
	498	HYDRAULIC KIT WITH BEARING AND SPACER	9	DIFFUSER									
			21	IMPELLER									
			276	RING (GUIDE -)									
			277	SUPPORT (GUIDE RING -)									
			477	SPACER									
			479	SPACER									
			487	BEARING									

Ricambi validi per i modelli con codice E2Bxxxxx/E2Exxxxx, per i modelli dove in etichetta non è presente alcun codice prodotto contattare il ns. ufficio Post-Vendita
 Spare parts valid for models E2Bxxxxx/E2Exxxxx. For models which in label is not indicated Part number, please contact our After Sales
 Pièces détachées valables pour les modèles E2Bxxxxx/E2Exxxxx. Pour les modèles pour lesquels il n'y pas d'indication, veuillez contacter notre Service Après Vente
 Ersatzteile gültig für Modelle mit Artikel Nummer E2Bxxxxx/E2Exxxxx Für Modelle, die kein Artikel Nummer, bitte nehmen Sie Kontakt mit unser Service Büro