

		DRW. DR100016			SPARE-PARTS															
SPARE-PARTS <small>Select language English</small>		VLRX 8			SPARE-PARTS KIT TABLE															
RECOMMENDED PARTS KIT	KIT REF. No.	KIT DESCRIPTION	COMPONENT REF. No.	COMPONENT DESCRIPTION	PUMP MODEL															
					VLRX 8-20F M	VLRX 8-20F T	VLRX 8-30F M	VLRX 8-30F T	VLRX 8-40F M	VLRX 8-40F T	VLRX 8-50F T	VLRX 8-60F T	VLRX 8-80F T	VLRX 8-100F T	VLRX 8-120F T	VLRX 8-140F T	VLRX 8-160F T	VLRX 8-180F T	VLRX 8-200F T	
	82	TIE ROD KIT (PUMP BODY -)	339	ROD		4 pc		4 pc	ZBR33580	4 pc										
			214	WASHER	ZBR33560				ZBR33580											
			97	NUT (TIE ROD LOCKING -)		4 pc	ZBR33570	4 pc												
			86	SCREW																
	200	BOLTS AND SCREWS KIT	274	GUARD COUPLING SCREW																
			237	SCREW (COUPLING -)																
			105	SCREW																
			273	RING (STOP -)																
			4	SCREW																
			76	NOZZLE (AIR -)																
	201	GASKET KIT	6	GASKET (FILLDRAIN PLUG -)																
			25	O-RING (PUMP BODY -)																
			21	IMPELLER																
			478	SPACER																
			277	SUPPORT (GUIDE RING -)																
			276	RING (GUIDE -)																
			9	DIFFUSER																
	323	STAGE (INTERMEDIATE - KIT)	21	IMPELLER																
			478	SPACER																
			277	SUPPORT (GUIDE RING -)																
			276	RING (GUIDE -)																
			9	DIFFUSER																
	*	371	482	ADJUSTMENT SPACER																
			286	SEAL (STATIONARY -)																
			287	SEAL (ROTATING -)																
			21	IMPELLER																
			477	SPACER																
			478	SPACER																
			277	SUPPORT (GUIDE RING -)																
			276	RING (GUIDE -)																
			9	DIFFUSER																
			21	IMPELLER																
			479	SPACER																
			276	RING (GUIDE -)																
			277	SUPPORT (GUIDE RING -)																
			487	BEARING																
			280	CHAMBER (DIFFUSER-BEARING-RING INTERM. -)																
	374	HYDRAULIC KIT WITH BEARING	280	CHAMBER (DIFFUSER-BEARING-RING INTERM. -)																
			280	BASE (PUMP -)																
	384	PUMP BODY KIT	280	CHAMBER (DIFFUSER-BEARING-RING INTERM. -)																
			280	BASE (PUMP -)																
	402	MOTOR KIT	488	COMPLETE MOTOR	ZBR21210	1 pc	ZBR21220	1 pc	ZBR30710	1 pc	ZBR21230	1 pc	ZBR30720	1 pc	ZBR21300	1 pc	ZBR30730	1 pc	ZBR21250	1 pc
			232	SHAFT																
			186	WASHER (SEAL COMPRESSION -)																
			71	WASHER	ZBR33700				ZBR33710				ZBR33720							
			73	NUT		1 pc														
			275	PIN (MOTOR COUPLING -)																
			237	SCREW (COUPLING -)	ZBR33280		ZBR33290	1 pc	ZBR33280	4 pc										
			103	COUPLING (MOTOR PUMP -)		1 pc														
	405	COUPLING KIT	275	PIN (MOTOR COUPLING -)		1 pc														
			237	SCREW (COUPLING -)		4 pc														
			103	COUPLING (MOTOR PUMP -)		1 pc														
	406	LANTERN KIT	27	LANTERN	ZBR33820	1 pc	ZBR33830	1 pc	ZBR33820	1 pc										
			274	GUARD COUPLING SCREW		2 pc														
			414	GUARD COUPLING	ZBR30350	2 pc	ZBR30360	1 pc	ZBR30350	2 pc										
			284	INTERCONNECTOR (COMPLETE SUCTION -)																
			21	IMPELLER																
			435	IMPELLER																
			276	RING (GUIDE -)																
			277	SUPPORT (GUIDE RING -)																
	452	HYDRAULIC KIT, FIRST STAGE	277	SUPPORT (GUIDE RING -)																
			163	BASE																
			25	O-RING (PUMP BODY -)																
			83	SLEEVE	ZBR34470	2 pc	ZBR34480	2 pc	ZBR34490	2 pc	ZBR34500	2 pc	ZBR34510	2 pc	ZBR34520	2 pc	ZBR34530	2 pc	ZBR34540	2 pc
			276	RING (GUIDE -)		1 pc		1 pc		1 pc		1 pc		1 pc		1 pc		1 pc		1 pc
	*	475	WEAR RINGS KIT	276	RING (GUIDE -)															
			277	SUPPORT (GUIDE RING -)																
			486	CONICAL SPRING																
	483	CHAMBER (UPPER - WITH DIFFUSER KIT)	308	CHAMBER (UPPER - WITH DIFFUSER)																
			6	GASKET (FILLDRAIN PLUG -)																
			86	PLUG (RECYCLING -)																
	484	RECYCLING PLUG KIT	86	PLUG (RECYCLING -)																
			493	COUPLING																
			21	IMPELLER																
			479	SPACER		1 pc														
			276	RING (GUIDE -)		1 pc														
			277	SUPPORT (GUIDE RING -)		1 pc														
			477	SPACER		1 pc														
			487	BEARING		1 pc														
			280	CHAMBER (DIFFUSER-BEARING-RING INTERM. -)		1 pc														
	498	HYDRAULIC KIT WITH BEARING AND SPACER	280	CHAMBER (DIFFUSER-BEARING-RING INTERM. -)		1 pc														